

Owner Registration



PLEASE COMPLETE YOUR OWNER REGISTRATION NOW AND MAIL TO PLANTRONICS. This is not a condition for warranty service, but will assist us in providing warranty service and technical support for the product.

[illegible]

Place of purchase/store name: _____

S10

Fold Here

1) Product acquired for use in* (check one)

Fold Here

Fold Here

2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841



Fold Here

Fold Here

Fold Here

1) Product acquired for use in: (Check one)

- ☐ Home/home office
☐ A call center
☐ An office outside the home
☐ Other _____

2) How many people are employed at the primary work location/business address of the user?

- ☐ 1-19 ☐ 100-249 ☐ 500-999
☐ 20-99 ☐ 250-499 ☐ 1,000+

3) Approximately how many hours per day does the user spend on the telephone for:

Work:

- ☐ 0-1 hr ☐ 4-5 hrs ☐ 8+ hrs
☐ 2-3 hrs ☐ 6-7 hrs

Personal:

- ☐ 0-1 hr ☐ 4-5 hrs ☐ 8+ hrs
☐ 2-3 hrs ☐ 6-7 hrs

4) Will this product be used primarily for: (Check one)

- ☐ Business use ☐ or both
☐ Personal use

*Thank you for filling out your owner registration. Please tear off at perforation below.
Fold to show Plantronics' address. Remove strip or moisten glue, seal and mail.*

5) Please indicate the age and gender of the primary user (for classification purposes only):

- Age:**
☐ Under 18 ☐ 40-49
☐ 18-39 ☐ 50 & over

- Gender:**
☐ Male ☐ Female

6) Are you the primary user of this product?

- ☐ Yes ☐ No

7) Plantronics or our affiliates may choose to contact you to request feedback or offer you product information on products or services we think may be of interest to you. Please specify if you prefer **not** to be contacted (check all that apply).


- ☐ By email ☐ By mail ☐ By telephone
☐ Do not contact me
☐ Do not allow your affiliates to contact me

S10

6/6/01

4:44 PM

Page 2



345 Encinal Street
Santa Cruz, California 95060
800.544.4660

www.plantronics.com

PLANTRONICS
World Leader in Communications Headsets


Printed in the U.S.A. 45329-01 © 4•2000 Plantronics Inc.

Telephone Headset System

Model S10

User Guide





DIAGRAM




DIAGRAM KEY

Base Front

- 1 Headset Holder
(P/N 46356-01)
- 2 Online Indicator Light
- 3 Listen Volume Control
- 4 Mute Indicator Light
- 5 Handset Indicator Light
- 6 Headset/Handset Switch
- 7 Headset Jack
- 8 Headset Indicator Light
- 9 Mute Button
- 10 Speak Volume Control
- 11 Tone Control
- 12 AC Power Adapter Jack
- 13 Handset Jack
- 14 Telephone Line Jack

Base Rear

- 15 Transmit Level Switch
- 16 Configuration Switch
- 17 Short Cord
(P/N 40974-01)
- 18 AC Power Adapter
(P/N 45671-01)

Headset

(Both Configurations Shown)

- 19 Cord
- 20 Clothing Clip
(P/N 43220-01)
- 21 Adjustable Headband
(P/N 43298-01)
- 22 Ear Hook (3 sizes)
(P/N 43297-01)
- 23 Headset Assembly
(P/N 45647-04)
- 24 Voice Boom
- 25 Pivot Ball Ring
(P/N 45650-01)
- 26 Ear Cushion Assembly
(P/N 43299-01)

WARRANTY AND SERVICE

How to Obtain Warranty Repairs

To obtain in or out of warranty service, please prepay shipment and return the unit to the appropriate facility listed below:

IN THE UNITED STATES

Plantronics Service Center
345 Encinal Street
Santa Cruz, CA 95060

Tel. (800) 544-4660

Fax (800) 279-0162

IN CANADA

Plantronics Service Center
1455 Pitfield Boulevard
Saint-Laurent, Quebec H4S 1G3

Tel. (800) 540-8363

(514) 956-8363

Fax (514) 956-1825




Please use the original container, or pack the unit(s) in a sturdy carton with sufficient packing material to prevent damage. Include the following information:

1. A proof-of-purchase indicating model number and date of purchase.
2. Bill-to address
3. Ship-to address
4. Number and description of units shipped
5. Name and telephone number of person to call, should contact be necessary
6. Reason for return and description of the problem


Damage occurring during shipment is deemed the responsibility of the carrier, and claims should be made directly with the carrier.

Try our Fax-on-Demand Information Services at:
Tel. (800) 544-4660 (Prompt #4)

The name Plantronics and the Plantronics logo are registered trademarks of Plantronics, Inc.
Quick Disconnect is a trademark of Plantronics, Inc.



⋮



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 51 BREA CA

POSTAGE WILL BE PAID BY ADDRESSEE

PLANTRONICS
PO BOX 9367
BREA CA 92822-8881




WELCOME

Thank you for selecting the S10 Telephone Headset System from Plantronics. This User Guide will help you install your S10 Telephone Headset System and learn its basic operation.

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. **Read and understand all instructions.**
2. **Follow all warnings and instructions marked on the product.** The symbol  identifies and alerts the user to the presence of important operating and service instructions.
3. **Unplug this product from the wall outlet before cleaning.**
Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
4. **Do not locate base unit near water, for example, near a bathtub, wash bowl, kitchen sink, or laundry tub, in a wet basement or near a swimming pool.**
5. **Do not place this product on an unstable cart, stand or table.** The product may fall, causing serious damage to the product.
6. **Slots and openings in the base unit and the bottom or back are provided for ventilation,** to protect it from overheating; these openings must not be blocked or covered. The openings should never be blocked by placing the product in the bed, sofa, rug or other similar surface. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation unless proper ventilation is provided.

IMPORTANT SAFETY INSTRUCTIONS


7. **Do not allow anything to rest on the telephone connection cord.** Do not locate this product where the cord will be abused by persons walking on it.
8. **Do not overload outlets and extension cords as this can result in the risk of fire or electric shock.**
9. **Never push objects of any kind into this product through base unit slots** as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.
10. **To reduce the risk of electric shock, do not disassemble this product,** but take it to qualified service personnel when service or repair work is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the product is subsequently used.
11. **Avoid using telephone equipment during an electrical storm.** There may be a remote risk of electric shock from lightning.
12. **Do not use the telephone equipment to report a gas leak in the vicinity of the leak.**

IMPORTANT SAFETY INSTRUCTIONS

13. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a) When the power supply cord or plug is damaged or frayed.
- b) If liquid has been spilled into the product.
- c) If the product has been exposed to rain or water.
- d) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions because improper adjustments of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- e) If the product has been dropped or the base unit has been damaged.
- f) If the product exhibits a distinct change in performance.

IMPORTANT SAFETY INSTRUCTIONS

- 14. Never install telephone wiring during a lightning storm.**
- 15. Never install telephone jacks in wet locations** unless the jack is specifically designed for wet locations.
- 16. Never touch uninsulated telephone wires or terminals** unless the telephone line has been disconnected at the network interface.
-  **17. Use caution when installing or modifying telephone lines.**
- 18. This product should be intended to be supplied by a Listed Class 2 Direct Plug-In Power Unit rated 9VDC 300mA.**
Plantronics Part No. 45671-01, rated at an input voltage of 120 VAC, 60Hz and an output voltage of 9 Vdc, 300mA.
- 19. This product requires AC power in order to operate.** In order to have phone service during a power outage, have another telephone available that is powered only by the telephone line.
- 20. Keep all product cords and cables away from operating machinery.**

SAVE THESE INSTRUCTIONS

STEP 1**SETUP**

The S10 Telephone Headset System is designed for use with an existing telephone.

G

Turn the S10 base over and insert the Headset Holder[®] 1.

F

Remove the handset cord from your telephone and plug it into the S10 Handset Jack[®] 13.

Using the Short Cord[®] 17, connect the S10 Telephone Line Jack[®] 14 to your telephone handset jack.

Connect the AC Power Adapter[®] 18 to the S10 AC Power Adapter Jack[®] 12 and a wall outlet.

Plug the Headset Cord[®] 19 into the Headset Jack[®] 7.

Put on Headset. Press the Headset/Handset Switch[®] 6 and pickup the Handset (Headset Indicator Light[®] 8 on). Slide the Configuration Switch[®] 15 until you hear a clear dial tone through the Headset. Trying other settings will not harm the amplifier or your telephone.

STEP 2

USING THE HEADSET

The Headset included with the S10 Telephone Headset can be used with the Adjustable Headband²¹ or with one of the Ear Hooks²².

HEADBAND USE

Snap the Headband²¹ into the back of the Headset Assembly. Press the Ear Cushion Assembly²⁶ onto the Headset Assembly²³, aligning the notch in the ring with the Voice Boom²⁴.

Place the Headset on either ear and adjust the Headset to a comfortable position by moving the Adjustable Headband²¹.

Position the Voice Boom²⁴ near the corner of your mouth.

EAR HOOK USE

Press the Pivot Ball Ring²⁵ onto the Headset Assembly²³. Insert one of the Ear Hooks²² into the Pivot Ball. You may need to try each size to find the most comfortable fit. Slip the hook over your ear and position the Voice Boom²⁴ near the corner of your mouth.

CLOTHING CLIP

The Clothing Clip²⁰ keeps the Headset free from the weight of the cord. Attach the clip to your clothing at about chest level. Allow enough slack in the cord (approximately 6 inches) to permit your head to move without pulling on the Headset or the Clothing Clip. You are now ready to make or receive calls.

STEP 3

PLACING A CALL

With the Headset in position, begin placing a call by pressing the Headset/Handset Switch **6**. (Headset indicator Light **3** on.)

E

Lift the Handset off-hook.

Make sure Mute Button **9** is off (Mute Indicator Light **4** off).

If you don't hear a dial tone, see **Troubleshooting** (page 13).

Dial a friend or co-worker. When your party answers, speak normally.

If your friend or co-worker cannot hear you or you hear a buzz or hum, move the Configuration Switch **13** to another setting. Adjust how loud you sound to the other party by first moving the Transmit Switch **15**, then fine-tuning with the Speak Volume Control **10**.

Adjust the volume of the other party's voice by using the Listen Volume Control **3**.

Test the Mute function by pressing the Mute Button **9** (Indicator **4** on). Release the Mute Button (Indicator off).

STEP 4

RECEIVING A CALL

With the Headset in position, when your telephone notifies you of an incoming call, press the Headset/Handset Switch⁶, (Headset Indicator⁸ on), place the Handset off-hook. Begin speaking.

E

The volume of the incoming call can be adjusted by moving the Listen Volume Control³ on the front of the S10.

MUTE FEATURE

When you activate the Mute Button⁹, the calling party cannot hear your voice but you will be able to hear the calling party.

STONE FEATURE

The treble and bass of the incoming call can be adjusted by moving the Stone Control¹¹.

TROUBLESHOOTING

I CANNOT HEAR A DIAL TONE

Make sure all cable connections are correct and firmly in place. Pay special attention that Handset and Short cords are properly connected.

G

Ensure AC Power Adapter¹⁸ is connected and power is on.

Make sure you have pressed the Headset/Handset Switch⁶ and the Headset Indicator⁵ is on.

Make sure the telephone Handset is off-hook.

Adjust Listen Volume Control³.

Adjust the Configuration Switch¹⁶.

Ensure that the Headset is centered on your ear.

CALLER CANNOT HEAR MY VOICE

Make sure the Mute Button⁹ is turned off (Indicator⁴ off).

Adjust the Transmit Switch¹⁵.

Increase the outgoing volume by adjusting the Speak Volume Control¹⁰.

Adjust Headset so the microphone is closer to your mouth.

I HEAR A HUM IN THE HEADSET

Adjust the Configuration Switch¹⁶ until the sound is clear. Trying other settings will not harm the amplifier or your telephone.

PLANTRONICS HELP DESK

The Plantronics Help Desk is ready to assist you!

Dial 1-800-544-4660, Monday through Friday 8:00 a.m. to 5:00 p.m. Pacific Standard Time or visit our website at www.plantronics.com.

SUPPLIES AND ACCESSORIES

INFORMATION ON SUPPLIES AND ACCESSORIES

For information on supplies and accessories call Plantronics at 1-800-544-4660 or visit our web site at www.plantronics.com.

See also Diagram Key for additional part numbers.

FCC REGISTRATION INFORMATION

FCC REQUIREMENTS—PART 68

1. The Federal Communications Commission (FCC) has established rules which permit this device to be directly connected to the telephone network. Standardized jacks are used for these connections. This equipment should not be used on party lines or coin phones.
2. If this device is malfunctioning, it may also be causing harm to the telephone network; this device should be disconnected until the source of the problem can be determined and until repair has been made. If this is not done, the telephone company may temporarily disconnect service.
3. The telephone company may make changes in its technical operations and procedures; if such changes affect the compatibility or use of this device, the telephone company is required to give adequate notice of the changes. You will be advised of your right to file a complaint with the FCC.
4. If the telephone company requests information on what equipment is connected to their lines, inform them of:
 - a. The telephone number to which this unit is connected.
 - b. The ringer equivalence number.
 - c. The USOC jack required (RJ-11C).
 - d. The FCC Registration Number.

Items (b) and (d) are indicated on the label. The Ringer Equivalence Number (REN) is used to determine how many devices can be connected to your telephone line. In most areas, the sum of the RENs of all devices on any one line should not exceed five (5.0). If too many devices are attached, they may not ring properly.

WARRANTY AND SERVICE

The following warranty and service information applies only to the U.S. and Canada. For information in other countries, please contact your local distributor.

Limited Warranty

Plantronics, Inc. ("Plantronics") warrants to the original consumer purchaser that, except for limitations and exclusions set forth below, this product shall be free from defects in materials and workmanship for a period of one (1) year from the date of original retail purchase ("Warranty Period"). The obligation of Plantronics under this warranty shall be limited to repair or replacement, at Plantronics' option, without charge, of any part or unit that proves to be defective in material or workmanship during the Warranty Period.

Exclusions From Warranty

This Warranty applies only to defects in factory materials and factory workmanship. Any condition caused by accident, abuse, misuse or improper operation, violation of instructions furnished by Plantronics, destruction or alteration, improper electrical voltages or currents, or repair or maintenance attempted by anyone other than Plantronics or an authorized service center, is not a defect covered by this Warranty. In such cases, Plantronics may charge you for materials and labor, even during the warranty period. Parts subject to wear and tear in normal usage are not covered by the Warranty.

Implied Warranties

Under state law, you may be entitled to the benefit of certain implied warranties. THESE IMPLIED WARRANTIES WILL CONTINUE IN FORCE ONLY DURING THE WARRANTY PERIOD. Some states do allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Incidental or Consequential Damages

NEITHER PLANTRONICS NOR YOUR RETAIL DEALER OR SELLING DISTRIBUTORS HAS ANY RESPONSIBILITY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING WITHOUT LIMITATION, COMMERCIAL LOSS OR PROFIT, OR FOR ANY INCIDENTAL EXPENSES, EXPENSES, LOSS OF TIME, OR INCONVENIENCE. Some states do not allow exclusion or limitation of incidental or consequential damage, so the above limitation or exclusion may not apply to you.

Other Legal Rights

This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.